


Operation Manual


PLS series flow sensor installation and use instructions



Installation instructions:

The installation needs to be used with the welded casing or the tee


(A)




Potential adjustment series sensors must follow this installation distance. The distance between the sensor and the straight pipe of the elbow or intersection should not be less than 4 times the pipe diameter, that is, $a \geq 4d$

When installing, the best installation direction is facing the mark point, that is, D1 installation direction, followed by D2 installation direction

(D1) When choosing an analog output sensor, you should follow this installation position (D2)




(B)




Button programming series sensors need to follow this installation distance. The distance between the front end of the sensor and the straight pipe at the bend or intersection should not be less than 10 times the pipe diameter, and the rear end should not be less than 5 times the pipe diameter. that is, $a \geq 10d$, $b \geq 5d$


(C)




When the medium cannot be fully filled the pipe, the sensor must be installed at the bottom of the pipe



If there is sediment in the pipeline, install the sensor horizontally on the side and ensure that there is no air pocket near the probe.



PLSX and PLSU series debugging methods



LED Meaning:

The flow sensor uses 6 LED to indicate the flow state.

Switch output:

4 Green LED: Over the setpoint (1,2,3, or 4 green LED lights on)
1 Yellow LED: Reach set point / exceed set point
1 Red LED: No setpoint was reached

According to the indication, the light of the rotary potentiometer will increase or decrease in sequence.



Adjustment setting

The flow sensor settings should follow the following steps:

- (1) The sensor must have been installed on the pipeline, select the required flow rate (i.e. set point), and can be adjusted after the equipment is powered on for 8S.
- (2) Open the Dustproof screw at the front end.
- (3) a. Establish the minimum flow rate
b. Adjust the potentiometer to light up the red LED light
c. Return to the normal flow rate so that at least the yellow light and one green light are on


Setting rules of switch output: (the flow rate V_n needs to be within the detection range)

	Step	Stationary state	Flowage	Below the set point	Above the setting point
Flow rate		1	1	1	1
Effective time		2	2	2	2
Potentiometer adjustment (switch point setting)		3	3	3	3
		4	4	4	4
Flow rate		5	5	5	5
Display after changing fluid state		6	6	6	6



* Switches without Bluetooth function do not need to set this step.
** If the sensor enters the setting interface without any operation, it will return to the working interface after 3min.

Wiring diagram



Technical data

(1) Model (2) Adjustable range W: Water O: Oil (3) Threaded type (4) Probe material (5) Response time: typical (6) Opening time: typical (7) Close time: typical (8) Temperature range (9) Pressure proof (10) Protection class (11) operating voltageUB (12) Output

(1)	(2)	(3)	(4)	(5)	(6)/(7)	(8)	(9)	(10)	(11)	(12)
PLSX(U)-...-AP6D... PLSX(U)-...-AN6D... PLSX(U)-...-VR6D... PLSX(U)-...-VR8D...	(W) 1...150cm/s (O) 3...300cm/s	1/4G 1/2G 1/2GL 18MN	304 Stainless steel	8 s	2 s/2 s	-20...+80 °C	100bar	IP67	24 VDC 24 VDC 24 VDC 230 VAC	PNP NPN Relays Relays
PLSN-...-PI6D... PLSN-...-NI6D... PLSN-...-AR6D...	(W) 1...150cm/s (O) 3...300cm/s	1/2G 18MN 50.5T	304 Stainless steel 316 Stainless steel	8 s	2 s/2 s	-20...+80 °C	100bar	IP67	24 VDC	4-20mA+PNP 4-20mA+NPN Relays

The SENTINEL's flow sensor can be used in the following applications

- Medium flow / flow rate decreases
- Medium flowing/stationary
- Media present/absent
- Liquid level detection

TIANJIN SENTINEL ELECTRONICS CO.,LTD.

Address: K2, Hitech green industry base,
Huayuan industrial park, Tianjin China
E-mail: info@sentinel-china.com
Tel: 86-22-85689572 83726972
Fax: 86-22-85689517
Post Code: 300384

